



Unplug the black cable at the back of your Wireless connection box. Make sure you switch off the power socket first.





Unplug the power cable that goes between your black power back-up and the wall socket.






Plug the power cable from the wall socket directly into your Wireless Connection box. Don't forget to switch the power socket back on.





Your power back-up is now disconnected.





Check your new setup, it should look like the diagram above. Don't forget to switch the power socket back on.